



Software Scheme 214

INV: ON/OFF Mot: ON/OFF p_m = XXX.X [bar]	INV: ON/OFF Mot: ON/OFF f = XXX.X [Hz]	INV: ON/OFF Mot. ON/OFF V_in = XXX [V]	INV: ON/OFF Mot. ON/OFF cosphi = X.XX	INV: ON/OFF Mot. ON/OFF p = XXXXX [W]	INV: ON/OFF Mot. ON/OFF STATUS: NORMAL ↓ ENTER ↓	MENU' ENT to access
no password: end user level password 1: installer level (default: 001) password 2: advanced level (default: 002)					Inverter life xxxxx h : xx m	
					Motor life xxxxx h : xx m	
					XXXXXXXXXXXXXX	
					XXXXXXXX h : XX m	
					PRESS ENTER BUTTON	

MENU'	MENU'	MENU'	Menu'
↓ Install param. ↓ ENTER	↓ Adv. param. ↓ ENTER	↓ Retrieve Init. Set. ↓ ENTER	↓ Change Init. Set. ↓ ENTER
Password 1	Password 2	Password 1	Password 2
Control mode	Motor type	ENT to retrieve	Language
Constant press.	Three phase/Single phase	Init config.	English
Unit	Rated motor Volt.	*PRESS RED BUTTON*	Unit
Bar/psi	V = XX [V]		Bar
F.s. press.sensor 20mA = XX.X [bar]	Voltage boost V = XX [%]		Motor type
			Three phase/Single phase
Offset sensors Press ENT	Rated Motor Ramp I = XX.X [A]		Rated motor amp. I = XX.X [A]
Max alarm pres. p = XX.X [bar]	Rated motor freq. f = XXX [Hz]		Rate motor freq. f = XXX [Hz]
Min alarm pres. p = XX.X [bar]	Max motor freq. f = XXX [Hz]		F.s. press.sens. 20mA = XX.X [bar]
Dry run cosphi cosphi = X.XX	Min motor freq. f = XXX [Hz]		Offset sensors Press ENT
Set pressure p = XX.X [bar]	Ramp up time t = XX [sec]		Max alarm press. p = XXX.X [bar]
p loss compens. p = XX.X [bar]	Ramp down time t = XX [sec]		Motor test START/STOP



Software Scheme 214

Set f. Min Q=0 fmin = XXX [Hz]	Ramp f min mot. t = XX [sec]		Rotation sense --->
Stop delay Q=0 t = XX [s]	PWM f = XX [kHz]		Set pressure p = XXX.X [bar]
Ramp Q=0 t = XXX.X [s]	Autorestart ON/OFF		Autorestart ON/OFF
Delta start press p = XXX.X [BAR]	Change PASSWORD2 ENT		INITIAL SETUP COMPLETED
Delta stop press p = XXX.X [BAR]	*PRESS RED BUTTON*		*PRESS RED BUTTON*
Ki XXXXX			
Kp XXXX			
Pump DOL 1 ON/OFF			
Pump DOL 2 ON/OFF			
Combo OFF/ON			
PI control Direct/Reverse			
Rotation sense → / ←			
Digital input 1 N.O / N.C			
Digital input 2 N.O. / N. C.			
Change PASSWORD1 ENT			
PRESS RED BUTTON			